

Installation Instructions:

Tools Required:

- Flat head Screwdriver
- Phillips head Screwdriver
- Silicon Gun + Silicone
- Rag for clean up
- Knife

Step 1:

Using a small Phillips head screwdriver, remove the two screws holding the old drainage bracket below the drain hole. This piece may also be held in place with silicone, a knife will help cut excess silicone away. The bracket will then pull away.



Step 2:

Apply a generous bead of silicone all the way around the flat part of the adapter.



Step 3:

Carefully lower the adapter in from the top of the hole opening, hose end facing down and outwards from the wheel. Press down firmly, the fit should feel tight and click into place. The top of the adapter will sit flush with the floor of the drain pan. Wipe away excess from surfaces with a rag. Allow the silicone to cure for 24h.



Step 4:

Once the silicone is cured, the adapter will be firmly set in place. You can now attach the drainage hose. One end is flared and will fit snugly over the adapter. Fasten it in place with a hose clamp and flat head screwdriver. All done! Enjoy



Contact:

0413790247

Rohanhill19@gmail.com

Instagram: @ro.lummyhill